









- CZ** **Popis produktu / Instalační manuál**
Licenční klíč OPC serveru
- D** **Produktbeschreibung / Montageanleitung**
OPC Server Lizenzschlüssel
- DK** **Produktbeskrivelse / Installationsmanual**
Licensnøgle til OPC-server
- E** **Descripción del Producto / Manual de Instalación**
Clave de licencia del servidor OPC
- F** **Description de produit / Manuel d'installation**
Clé de licence du serveur OPC
- GB** **Product description / Installation manual**
OPC Server License Key
- GR** **Περιγραφή προϊόντος / Οδηγίες συναρμολόγησης**
Κλειδί άδειας χρήσης
- H** **Termékleírás / Telepítési kézikönyv**
OPC-kiszolgáló licenckulcsa
- I** **Descrizione prodotto / Manuale di installazione**
Chiave di licenza del server OPC
- NL** **Productomschrijving / Installatiehandleiding**
OPC Server Licentiesleutel
- P** **Descrição de Produto / Manual de Instalação**
Chave de licença para servidor OPC
- PL** **Opis produktu / Instrukcja instalacji**
Klucz licencji serwera OPC
- RO** **Prospecte / Manual de Instalara**
Cheie de licență Server OPC
- RUS** **Техническое описание / Инструкция по установке**
Лицензионный ключ сервера OPC
- TR** **Ürün tanımı / Kurulum kılavuzu**
OPC Sunucusu Lisans Anahtarı





					
1	2	3	4	S	≤ 4096
0064	0064	0064	0064	0256	✓
0064	0128	0512	1024	1728	✓
0128	0512	0512	1024	2176	✓
0512	0512	0512	0512	2048	✓
0512	0512	1024	OPC	2048	✓
0128	0512	1024	2048	3712	✓
0512	0512	1024	2048	4096	✓
1024	1024	1024	OPC	3072	✓
1024	1024	2048	OPC	4096	✓
2048	2048	2048	2048	8192	✗
512	2048	2048	OPC	4608	✗
1024	2048	2048	OPC	5120	✗
2048	2048	2048	OPC	6144	✗

